


# Mk.1 CLOCKWORK ESCAPEMENT

The Escapement can be fitted, where most convenient to the model, preferably as near as possible to the point of control. The control arm permits several methods of drive, either by fine piano wire, cords direct, or cords over pulleys. Any convenient position, either vertical or horizontal, is permissible. In boats the control arm can be fitted direct to the rudder operating bar.

The Escapement can be wound up either by the extension which projects through the slot in the control arm, or by the spring housing underneath, both in a clockwise direction. If wound up fully, release by hand one full turn on star wheel to ease spring tension. Escapement provides for about 200 movements, 50 complete revolutions of star wheel. Battery voltage  $4\frac{1}{2}$  to 6 volts.



---

**ELECTRONIC DEVELOPMENTS  
(SURREY) LIMITED,  
18 VILLIERS ROAD,  
KINGSTON-ON-THAMES,  
SURREY.**